


# AIRPORT DIAGRAM

BURBANK/ BOB HOPE (BUR)  
BURBANK, CALIFORNIA

AL-67 (FAA)

ATIS  
134.5  
BURBANK TOWER  
118.7 254.3  
GND CON  
123.9 348.6  
CLNC DEL  
118.0 348.6



CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.  
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

118° 22' W

118° 21' W

BURBANK, CALIFORNIA  
BURBANK/ BOB HOPE (BUR)

# AIRPORT DIAGRAM


SW-3, 22 OCT 2009 to 19 NOV 2009

SW-3, 22 OCT 2009 to 19 NOV 2009

34° 12.5' N

34° 12.0' N

34° 11.5' N



JANUARY 2005  
ANNUAL RATE OF CHANGE  
0.1° W

CONTROL TOWER  
825±

EMAS  
170 X 350

RWYS 8-26, 15-33  
S30, D180, ST175, DT300

ELEV  
694

ELEV  
697

FIELD  
ELEV  
778

857

AIRCRAFT  
HOLDING AREA  
AND BY-PASS  
APRON

ILS HOLD

FIRE STATION

FAA ASR  
COMPLEX

MILLION  
AIR

LAHSO

PASSENGER TERMINAL &  
ADMINISTRATION

6885 X 150

5802 X 150

ELEV  
694

ELEV  
694

ELEV  
697

FIELD  
ELEV  
778

857

AIRCRAFT  
HOLDING AREA  
AND BY-PASS  
APRON

ILS HOLD

FIRE STATION

FAA ASR  
COMPLEX

MILLION  
AIR

LAHSO

PASSENGER TERMINAL &  
ADMINISTRATION

6885 X 150

5802 X 150

ELEV  
694

ELEV  
694

ELEV  
697